



Chairside Workflow

1. Intraoral Scans

- Scan the upper and lower arches.
- Select the arch(es) needing a full denture.
- If scanning is difficult, take a conventional impression and scan the impression or the model instead.

2. Wax Bite Rim & Bite Registration

- Seat the wax bite rim and guide the patient into proper bite.
- Apply a light layer of body wash to improve border molding and accuracy.
- Mark the wax bite rim:
 - Midline
 - Canine lines
 - Smile line
- Apply blue mousse to record the bite.

3. Patient Photos (Recommended)

- Frontal photo with patient smiling naturally and bite rim in place.
- Right and left profile photos with patient smiling naturally and bite rim in place.
- Frontal photo with cheek retractors and bite rim in place (if possible).

4. Denture Scanning

- Select the arch(es) for full denture fabrication.
- Choose “Denture” in the scanner software when scanning wax rims.
- Perform a 360° extraoral scan of the wax bite rim(s).

5. Bite Scan

- **Single arch:** Scan intraorally with wax bite rim in place, molar to midline, using blue mousse.
- **Dual arch:** Scan both arches together in occlusion extra orally, full arch molar to molar, using blue mousse.